



Model No. **CZ-RTC6BLW**  
**CZ-RTC6WBLW**



Installation Instructions  
separately attached

Page

● Safety precautions .....	3
● Part names .....	6
• Control panel / Top screen .....	6
• Screen display .....	8
• Operation guide .....	8
● Basic operations .....	9
● Menu list .....	12
● ECONAVI function .....	13
● nanoe™ X function .....	16
● Filter sign .....	18
● Outing function .....	19
● Clock/Clock type/Controller name .....	21
● Touch sound/Contrast .....	22
● Backlight/Language .....	23
● Contact address/Display mode .....	24
● Setting information list .....	25
● Bluetooth® settings .....	28
● Wireless LAN settings .....	60
● Troubleshooting .....	88
● Specifications .....	95
● Firmware Update Function for Wireless LAN functionality .....	97
● Software License Information (Bluetooth® functionality) .....	97
● Software License Information (Wireless LAN functionality) .....	99

## English

Before operating the unit, read these Operating Instructions thoroughly and keep them for future reference.

Thank you for purchasing the Panasonic wired remote controller.

- Read the Operating Instructions carefully for safe use. This manual describes the Operating Instructions of the wired remote controller. Read this manual as well as operating instructions supplied with indoor units and outdoor units.
- **Be sure to read the “Safety precautions” (P.3) before use.**
- **This product is a remote controller that comes equipped with Bluetooth® wireless technology.**  
**Be sure to read the “General precautions for Bluetooth® functionality” (P.4) before use.**
- Keep this manual with operating instructions supplied with indoor units and outdoor units in a safe place.
- Be sure to keep this manual in a place easily accessible by users. In the case of user change, be sure to give this manual to the new user.

## NOTICE


The English text is the original instructions. Other languages are translation of the original instructions.

### ■ You can use your mobile device (a smartphone, for example) to control the air conditioner.

When you want to make settings for a variety of functions when you are near the remote controller



Bluetooth®  
functionality



Remote Controller

“Panasonic H&C Control App” (via Bluetooth® functionality) (P.28)

When you want to perform some basic operations when you are out and about

Internet  
Wireless LAN



“Panasonic Comfort Cloud” app (via wireless LAN network) (P.60)

## Note

- The Bluetooth® functionality and Wireless LAN functionality cannot be used simultaneously.

# Safety precautions



## WARNING

This symbol refers to a hazard or unsafe practice which can result in severe personal injury or death.



## CAUTION

This symbol refers to a hazard or unsafe practice which can result in personal injury or product or property damage.



Matters to be observed



Prohibited matters



## WARNING



Do not use this appliance in a potentially explosive atmosphere.

In case of malfunction of this appliance, do not repair by yourself. Contact the sales or service dealer for repair and disposal.



In case of emergency, remove the power plug from the socket or switch off the circuit breaker or the means by which the system is isolated from the mains power.



## CAUTION



This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

<for European market only>

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.

This equipment is not suitable for use in locations where children are likely to be present.



- Do not operate with wet hands.
- Do not wash with water.

## Safety precautions

### [General precautions for ECONAVI]

#### WARNING

- Do not use the ECONAVI function in a room with disabled persons or infants only. Due to their limited motions, the ECONAVI sensor may judge no person is present, causing the indoor unit to stop the operation.

### [General precautions for Bluetooth® functionality]

#### WARNING

- Do not use the remote controller where pacemaker users may be around. If used, turn off Bluetooth® functionality.
  - Bluetooth® functionality may cause pacemakers to malfunction and lead to an accident.
- Do not use the remote controller near electrical medical devices. If used, turn off Bluetooth® functionality.
  - Bluetooth® functionality may cause these devices to malfunction and lead to an accident.
- Do not use the remote controller near automatic doors, fire alarms, or other automatically controlled devices. If used, turn off Bluetooth® functionality.
  - Bluetooth® functionality may cause these devices to malfunction and lead to an accident.

#### CAUTION

- This product is permitted for use only in the country where it was purchased.
- This product uses signals in the 2.4 GHz band.
  - Signals in the 2.4 GHz band are used by medical devices, other similar devices, and nonlicensed amateur radio stations (hereafter referred to as other radio stations).
    1. Before using this product, make sure there are no other radio stations in the vicinity.
    2. If a radio interference occurs between this product and other radio stations, move the product or stop using the product (turn off Bluetooth® functionality).
    3. If problems with radio interference occur, consult the dealer from which the product was purchased.
- Keep an appropriate distance between the product and radio-emitting devices, such as cordless phones, microwave ovens, and wireless LANs, to prevent Bluetooth® interference from these devices that can affect normal operation and performance of the product.
- The following actions may be punishable by law.
  - Disassembling or alteration of this product
  - Removal of certification labels
- The maximum line-of-sight distance of this product is 10 meters. This distance will be shorter when obstacles or people are in the path of radio waves or radio interference from appliances (e.g., microwave ovens) exists.

### **[General precautions for Wireless LAN functionality]**

- The wireless LAN coverage must include the remote controller installation location.
- Please ensure that the Router supports the WPA2-PSK (TKIP/AES) encryption.
- To complete connection of this remote controller to the wireless network service the Router may be required.
- The End user should read and accept the Terms of use and Privacy Notice in the contents of “Panasonic Comfort Cloud” app.
- There is a risk of unauthorised operation if a vulnerable password is set for the wireless router.
- Users are responsible for all costs associated with downloading and using the “Panasonic Comfort Cloud” app and the remote controller, including without limitation all fees charged by your Device carrier and internet service provider and any other wireless LAN or data access charges.
- Panasonic remote controller is designed for communication to the “Panasonic Comfort Cloud” app.
- Third party wireless LAN interfaces cannot be connected to the “Panasonic Comfort Cloud” app.
- Updates to the service may mean there are changes to the design of the “Panasonic Comfort Cloud” app screen and display.

### **[Precautions for using mobile device application]**

- When operating an air conditioner from a remote controller located outside the visibility of the air conditioner, make sure that the operation of the air conditioner will not negatively affect its surroundings or the occupants beforehand.
- When occupants include children, elderly people, people with ailments, or people with disabilities, make sure the product is used in the presence of a capable, supervising adult.
- When one or more people are in a room with an air conditioner, let them know beforehand that the air conditioner is going to be operated from a remote controller located outside the visibility of the air conditioner.
- Children should be supervised or instructed to stay away from the product.
- Poor radio-wave conditions due to an existence of obstacles or radio-emitting devices, such as a microwave oven, in the vicinity of the product can lead to a non-response error. Periodically check the operating conditions of the product.
- Regarding Bluetooth® functionality, the maximum line-of-sight distance of this product is 10 meters. Obstacles in the path of radio waves can shorten this distance. If a problem occurs, remove the obstacles or shorten the distance between this product and the connected device.
- It is recommended to lock the mobile device screen to prevent inadvertent operation of the air-conditioning system.


# Part names

## Control panel / Top screen

The control panel colour of CZ-RTC6WBLW is white.

**Appears when ECONAVI is being set to ON.**  
(ECONAVI settings are possible only when fitted with ECONAVI panel/ECONAVI sensor.)

**Connected to a wireless LAN network via a router (P.63)\***



### Setting information icon


- Only the partial settings can be checked on the top screen. To check all the settings (P.25)
- You can limit the number of icons to be displayed to simplify the display. (P.24)

### Setting information icons displayed on the top screen




- Icon details (P.26)


\* The Bluetooth® functionality and Wireless LAN functionality cannot be used simultaneously.

**Note**

Press centre



No glove




No pen

- If no operation is performed for an extended period, the backlight turns off to save electricity. (Press any button for illumination.)

## Screen display

### Internal cleaning in process

- To stop the internal cleaning operation

Press .


- To resume operation

Press .



### Internal drying in process

- To stop the internal drying operation

Press .

- To resume operation

Press .



### Key operations locked

Keys are locked so operations are not possible.

- To return to the top screen

Press .



### Prohibited

Being centrally controlled, operation is not possible.

- To return to the top screen

Press .




### Operation stop screen





### When inspection is required


Refer to "Troubleshooting" (P.88).



## Operation guide

The currently operable content is displayed.

- : Menu button
- : Enter button







# Basic operations

## 1 Start operation.

Press .

- Pressing  after recovery from mains power failure will resume operation with the contents before mains power failure has occurred.
- It is possible to set the screen in Step 2 as the top screen when starting operation. (P.24 "Display mode")  
In that case, skip Step 2 below.




### ■ To stop operation

Press .


## 2 Check the current operating status.


Press .


- When no operation is performed for several seconds, the display returns to the top screen.



## 3 Select the item to set.

Press .  
(Repeat)

- When no operation is performed for several seconds, the display returns to the top screen.
- "SET TEMP." (Set temperature) is not displayed in Fan mode (.



### Note


- For models that cannot change the airflow direction, "FLAP" is not displayed.

## Set temperature

### 4 Change the setting. (0.5 °C steps)

Press → .  
(Press to finish.)



- **Cool/Dry** : 18.0 °C to 30.0 °C
- **Heat** : 16.0 °C to 30.0 °C
- **Auto** : 17.0 °C to 27.0 °C



## Operation mode (e.g. Cool, Heat, etc.)

4 Press → .  
(Press to finish.)

- (Auto): The mode is automatically switched to Cool or Heat to achieve the set temperature.
- Operation modes that cannot be set are not displayed.





## Fan speed

### 4 Change the setting.

Press → .  
(Press to finish.)

- (Auto): Cannot be selected in Fan mode.
- Depending on the model, selectable fan speed may differ.



\* Depending on the model, either of the displays appears.

## Flap

4


### Change the setting.

Press → .

(Press to finish.)

: Swing

- Pressing during swing can stop the flap at your preferred position.
- The swing and airflow direction on the remote controller is not synchronised with the flap movement.
- Depending on the type of indoor unit and operation mode, Flap can be set in 3 levels.
- The flap display differs from the actual flap angle.



## Menu

4

### Select the menu item.

Press → .

#### ■ To return to the top screen

Press .

- See "Menu list" (P.12) for the menu items.
- When no operation is performed for several minutes, the display returns to the top screen.
- The menu screen can also be displayed if you press while stopped.



# Menu list

	Number for the selected item	Total number of items
		XX/XX
1	ECONAVI	
2	nanoeX	
3	Filter sign	
		XX/XX
4	Outing function	
5	Clock	
6	Clock type	
		XX/XX
7	Controller name	
8	Touch sound	
9	Contrast	
		XX/XX
10	Backlight	
11	Language	
12	Contact address	
		XX/XX
13	Display mode	
14	Bluetooth	
15	WLAN	

1	<b>ECONAVI*</b>	Turns the ECONAVI function ON/OFF.	P.13
2	<b>nanoeX*</b>	Turns the nanoe™ X function ON/OFF.	P.16
3	<b>Filter sign</b>	Resets the time to filter cleaning.	P.18
4	<b>Outing function</b>	Prevents the room temperature from rising too high (or dropping too low) when no one is in the room.	P.19
5	<b>Clock</b>	Sets the present date and time.	P.21
6	<b>Clock type</b>	Sets the type of clock display.	P.21
7	<b>Controller name</b>	Confirms the remote controller name.	P.21
8	<b>Touch sound</b>	Turns the operation sound ON/OFF.	P.22
9	<b>Contrast</b>	Sets the screen contrast.	P.22
10	<b>Backlight</b>	Sets the backlight brightness of the screen.	P.23
11	<b>Language</b>	Sets the display language.	P.23
12	<b>Contact address</b>	Confirms the contact address and telephone number for servicing.	P.24
13	<b>Display mode</b>	Changes the display of the top screen.	P.24
14	<b>Bluetooth</b>	Makes Bluetooth® settings.	P.28
15	<b>WLAN*</b>	Makes wireless LAN settings.	P.60

\* Some menus cannot be used if the function is not fitted. If unavailable menus are selected, the display shown on the right appears.



• If the menu operations are locked, the display shown on the right appears and the menu cannot be used.



# ECONAVI function

This function is available by attaching an optional ECONAVI sensor. The ECONAVI sensor detects human activity and conserves energy based on the activity level.

## Overview of the ECONAVI function

<p><b>High activity</b></p>	<ul style="list-style-type: none"> <li>• Cooling: Target temperature is the same as the set temperature.</li> <li>• Heating: Target temperature is 1 °C lower than the set temperature.</li> </ul>
<p><b>Low activity</b></p>	<ul style="list-style-type: none"> <li>• Cooling: Target temperature is 1 °C higher than the set temperature.</li> <li>• Heating: Target temperature is the same as the set temperature.</li> </ul>
<p><b>No one in the room</b></p> <ul style="list-style-type: none"> <li>• When the sensor detects movements in the room which has been empty, it will resume operation to match with the activity level.</li> </ul>	<p><b>No one in the room for 20 minutes</b></p> <ul style="list-style-type: none"> <li>• Cooling: Target temperature is 2 °C higher than the set temperature.</li> <li>• Heating: Target temperature is 2 °C lower than the set temperature.</li> </ul> <p><b>No one in the room for 3 hours*</b></p> <ul style="list-style-type: none"> <li>• When no one is in the room for approx. 3 hours* or more, the unit operates in the specified Absence operation mode.</li> </ul> <p>* This depends on the type of indoor unit.</p>

### Note

- ECONAVI can be set using the separately sold ECONAVI panel or by connecting the holder on the wall.
- Even when target temperature is changed through the ECONAVI function, the set temperature shown in the remote controller does not change.
- Even when Cooling/Heating is changed to Fan through the ECONAVI function, the operation mode shown in the remote controller will still be Cooling/Heating.
- It is possible to choose from the following options for the operation to be performed after a lapse of 3 hours\* since the room has been empty.
  - Operates in the Fan mode only.
  - Stops and resumes operations after human movements are detected.
  - Stops and will not resume operations even after human movements are detected.
  - Continues operation in the current mode.

If you need to do so, please contact the dealer.

\* This depends on the type of indoor unit.

- Turn the ECONAVI function OFF if:
  - You want to maintain the room temperature at a set temperature.
  - You want to keep air conditioner running while nobody is in a room.
  - The sensor fails.
  - Only infants, babies, or people only with disabilities are in the room.
- When operating more than one indoor unit, the energy-saving effect may be reduced depending on the room condition.


## ECONAVI

### 1 Display the menu screen.

#### ■ When stopped

Press .

#### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .



### 2 Select [ECONAVI].

Press   → .





### 3 Select [ON] or [OFF].

Press   →  → .

(Press to finish.)

- When ECONAVI is set to ON, "**ECONAVI**" will appear on the top screen.
- When the indoor unit is stopped, "**ECONAVI**" will disappear.



#### Note

- If the function is not fitted, the display shown on the right appears and this function cannot be used.



# nanoe™ X function

## Display during operation of nanoe™ X

**nanoeX** : Under operation of nanoe™ X



**nanoe™ X** For a fresher and cleaner environment  
nanoe™ X generates negative ions using the air in the room to give a healthy air. It also reduces the smell in the room, and constrains propagations of mold and bacteria.







## nanoe™ X

### 1 Display the menu screen.

#### ■ When stopped

Press .

#### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .



### 2 Select [nanoeX].

Press   → .





### 3 Select [ON] or [OFF].

Press   →  → .

(Press to finish.)

- When nanoe™ X is set to ON, "**nanoeX**" will appear on the top screen.
- When the indoor unit is stopped, "**nanoeX**" will disappear.



#### Note

- In the following case, the message appears and this function cannot be used.
- When the indoor unit is not supported or the nanoe™ X kit is not equipped.



# Filter sign


When the cleaning time comes, the icon shown on the right appears on the top screen.




## Filter sign reset

### 1 Display the menu screen.


#### ■ When stopped

Press .

#### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .



### 2 Select [Filter sign].

Press   → .



### 3 Select [Filter sign reset].

Press  → .

(Press to finish.)


(The filter cleaning time count is reset.)



# Outing function

This function prevents the room temperature from rising too high (or dropping too low) when no one is in the room due to outing, etc.



## General Performance of the Outing Function



### [Precautions]

- The outing control only starts/stops the air conditioner. It does not change the operation mode/temperature setting. Therefore, the operation mode/temperature needs to be set beforehand so that the outing function turns on the air conditioner with your desired operation mode/temperature setting.
- If the room temperature rapidly changes, the room temperature may get over the upper or lower limit when the outing function is activated.
- The outing function is invalid during FAN/AUTO operation mode.
- The air conditioner's stop order (stated in ② / above) is valid only when the outing function is operated. If operated using other remote controller (or a central control device such as System Controller), the outing function does not work.

### • Outing function indication

Outing function indication	Status
Off	The outing function is not set.
Flashing 	The outing function is now being set, or under operation.
Lighting 	Although the outing function is set, not under operation.

### Note

- A remote controller loses outing function operation information when electrical supply is cut for seventy two hours or more during outing function. Following power restoration, the unit does not operate in outing function mode.


## Outing function

### 1 Display the menu screen.

■ **When stopped**

Press .

■ **When operating**


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




### 2 Select [Outing function].

Press   → .





### 3 Select [Enable/disable].

Press   → .




### 4 Select [Enable].

Press   → .




### 5 Select [Set limit temp.].


Press   → .





### 6 Set the temperature range. (0.5 °C steps)

Press   →  →   →  → .

(Press twice to finish.)



#### To disable Outing function

1. Start with Step 1 and select [Disable] in Step 4.
2. Press .
3. Press  twice to finish.

# Clock/Clock type/Controller name


Steps 1 and 2 are common operations for each item.

## 1 Display the menu screen.

### ■ When stopped

Press .

### ■ When operating


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .







## 2 Select the item to set.

Press   → .




## Clock

## 3 Set the present date and time.

Press   →  → .





(Repeat) (Press to finish.)

- [-] appears in situations where the clock is reset, such as when power is not supplied to the remote controller for 24 hours or more.





## Clock type

## 3 Select the type to display.

Press   →  → .

(Press to finish.)




## Controller name

The controller name can be set only with the “Panasonic H&C Control App”.

## 3 Confirm the name.

Confirm, then press .

(Press twice to finish.)




# Touch sound/Contrast


Steps 1 and 2 are common operations for each item.

## 1 Display the menu screen.

### ■ When stopped

Press .

### ■ When operating


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .







## 2 Select the item to set.



Press   → .



## Touch sound





## 3 Select [ON] or [OFF].


Press   →  → .  
(Press to finish.)



## Contrast

## 3 Set the screen contrast.

Press   →  → .  
(Press to finish.)



# Backlight/Language


Steps 1 and 2 are common operations for each item.

## 1 Display the menu screen.


### ■ When stopped

Press .

### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .







## 2 Select the item to set.

Press   → .




## Backlight

## 3 Set the backlight brightness of the screen.





Press   →  → .

(Press to finish.)




## Language

## 3 Select the language to display from among 7 languages shown on the right.

Press   →  → .

(Press to finish.)

- Default setting: ENGLISH



# Contact address/Display mode


Steps 1 and 2 are common operations for each item.

## 1 Display the menu screen.

### ■ When stopped

Press .

### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .



## 2 Select the item to set.

Press   → .



## Contact address


The contact address can be set only with the “Panasonic H&C Control App”.

## 3 Confirm the name and the contact number.

Confirm, then press .

(Press twice to finish.)

- If you need to contact for servicing, check the back cover of the operating instructions for indoor units or outdoor units.



## Display mode

## 3 Select the display mode for the top screen.

Press   →  → .

(Press to finish.)

### • Detailed:



The number of icons is not limited.  
During operation, the current operation mode, fan speed, and flap are displayed on the top screen.  
(Refer to Step 2 in “Basic operations” (P.9))

### • Standard:

The number of icons is not limited.

### • Simple:

Limits the number of icons displayed on the top screen to simplify the display.






# Setting information list

This provides the meanings of setting information icons.

## 1 Display the setting information screen.


Press  on the top screen.  
(Press and hold for 4 seconds or more.)



## 2 Select the icon.

Press   → .



- Only icons currently being displayed on the screen are displayed here.




## 3 Check the meaning of the icon.

Confirm, then press  → .
























(Press to finish.)

- Scroll through the screen with  .


















## Setting information list

### ■ Setting information icon list

Icon	Description	Page
	The indoor unit is stopped or slight blow operation is in process.	–
	The indoor unit is turned on after a problem such as a power failure is resolved.	–
	The indoor unit is in defrosting operation.	–
	Air flow direction is locked on some units. *	–
	Switching between Heat and Cool/Dry mode is prohibited (Switching to Auto mode is also prohibited.).	–
	Remote control operation is restricted by a central control device.	P.8
	The indoor unit filter needs to be cleaned.	P.18
	Time to replace engine oil in the outdoor unit. Replace the oil. (Only when the gas heat pump air conditioner is used.)	–
	“ON/OFF timer” is set. *	–
	Separate timers are set for each day. *	–
	Energy saving is on to control energy consumption. *	–
	The operation capacity of the outdoor unit is restricted.	–
	Units are operated at the capacity set by schedule. *	–
	If the set temp is changed, the temp will return to the registered set temp after a preset time. *	–
	Upper and lower set temperature limits have been changed. *	–
	Operation automatically stops in the set time zone at the set interval. *	–
	“Repeat off timer” is set. *	–
	Operation capacity of outdoor unit is controlled in the set time zone to lower noise. *	–
	The temperature sensor of the remote controller is detecting the room temperature.	–
	“Operation lock” is set. • To unlock: Press  and  on the top screen. (Press and hold for 4 seconds or more.)	P.8
	Fresh air is used for ventilation. * (Only when connecting a heat exchange ventilation unit or connecting a commercially sold fan)	–

(Continued on next page)

Icon	Description	Page
	Starts/stops automatically to maintain a set temperature range even when off.	P.19
	There are one or more units currently set to Direct airflow. *	–
	There are one or more units currently set to Indirect airflow. *	–
	There are one or more units currently set to Air circulation operation. *	–
	The rotation operation is set. *	–
	Internal cleaning is in process.	P.8
	Internal drying is in process.	P.8
	Connected with a mobile device via Bluetooth® functionality	P.28
 (alternately)	Bluetooth® module is considered abnormal.	P.91
	Connected to a wireless LAN network via a router (Signal strength: Strong)	P.62
	Connected to a wireless LAN network via a router (Signal strength: Moderate)	
	Connected to a wireless LAN network via a router (Signal strength: Weak)	
	Connected to a wireless LAN network via a router (Signal strength: No signal)	
 (alternately)	Wireless LAN module is considered abnormal.	P.91
 (alternately)	Clock not set (reset due to a power outage)	P.90


\* Can only be set using the “Panasonic H&C Control App”

# Bluetooth® settings

Before use, confirm the version of the OS on the mobile device and the Bluetooth® version (P.95), and install the “Panasonic H&C Control App” onto the mobile device. In addition, be sure to read the “General precautions for Bluetooth® functionality” (P.4).

## Panasonic H&C Control App

You can use the “Panasonic H&C Control App” on your mobile device to operate the air conditioning unit, make detailed settings for functions such as the energy saving function, etc.



### ■ Functions that can be set with the “Panasonic H&C Control App” (some examples)

#### ● Weekly timer\*1

The operation ON/OFF schedule or temperature setting schedule can be set by setting the day and time.

#### ● Energy saving operation On/Off

Operates in an energy saving mode.

#### ● Power consumption monitor\*2

Displays the approximate power consumption for a day, a week or a year.

#### ● Rotation and Backup functions\*3

The rotation functions helps you equalize the operating times.

The backup function allows operation to continue even when an error has occurred.

\*1 This is not synchronised with the Weekly timer set with the “Panasonic Comfort Cloud” app.

\*2 Supported only by models that support the power consumption monitor


\*3 Rotation operation is available only when there is a control group of 2 PAC systems (each system being a combination of 1 outdoor unit and 1 indoor unit).

### ■ Installing the “Panasonic H&C Control App”

#### For iOS user

- Open 
- Search for “Panasonic H&C Control App”.
- Download and install.

#### For Android™ user

- Open 
- Search for “Panasonic H&C Control App”.
- Download and install.

- The “Panasonic H&C Control App” is free, but the communication fees for downloading it and updating it are at the customer’s expense.
- The “Panasonic H&C Control App” screen may change without notice due to updates.
- Functions are not displayed in the “Panasonic H&C Control App” screen if the air conditioner does not support them.
- The screen operations are the same on iOS and Android™. The iOS screen has been used in the examples.


## Bluetooth® functionality

### 1 Display the menu screen.

#### ■ When stopped

Press .

#### ■ When operating

Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




### 2 Select [Bluetooth].

Press   → .



### 3 Select [Enable/disable].

Press   → .




### 4 Select [Enable].



Press   →  → .

(Press twice to finish.)

- [Enable] cannot be set for the Bluetooth® functionality and Wireless LAN functionality simultaneously.




#### To disable Bluetooth® functionality


1. Start with Step 1 and select [Disable] in Step 4.
2. Press .
3. Press  twice to finish.

## Bluetooth® settings





You can also set [Enable/disable] wireless communication with the following procedure.

### 1. Display the wireless setting screen.


Press  on the top screen.  
(Press and hold for 4 seconds or more.)



### 2. Select (enable) or (disable).

Press   →  → .

(Press to finish.)



- **Bluetooth:**  
This setting is the same as Step 4 on page 29.
- **WLAN (Wireless LAN):**  
This setting is the same as Step 4 on page 61.
- (enable) cannot be set for the Bluetooth® functionality and Wireless LAN functionality simultaneously.

### ■ datanavi

This unit supports datanavi.  
For details on the usage, supporting regions, etc., visit the following URL.  
<https://datanavi.ac.smartcloud.panasonic.com/global/>



## Connecting with the “Panasonic H&C Control App”

Before connecting, set Bluetooth® functionality to [Enable] on the remote controller. (Step 4 on page 29)

When connecting, try getting the mobile device as close as possible to the remote controller.

### 1 Start the “Panasonic H&C Control App”.

- Remote controllers in the vicinity are displayed on the Home screen.
- Remote controllers that have been paired have “Bluetooth” displayed to the left.




: Remote controller last connected



: Unconnected remote controller within Bluetooth® communication range



: Connected remote controller outside Bluetooth® communication range




### 2 Select the remote controller you want to operate.

#### ■ Mobile device

Tap “”.

- If the remote controller is not displayed, slide down to update and the remote controller is detected.

Tap



■ When making a Bluetooth® connection for the first time, go to Step 3.

■ For the second and subsequent Bluetooth® connections, go to Step 5.

## Bluetooth® settings


### 3 Confirm the numbers on the mobile device match the 6 digits on the remote controller.

- If the numbers do not match, check the remote controller you want to connect again. (Step 2)





### 4 Start connecting.

- **Mobile device**  
Tap "Pair".
- **Remote controller**  
Press .



### 5 Confirm that the Bluetooth® connection is completed.

- "  " is displayed on the top screen when the Bluetooth® connection is established. Once this step is complete, subsequent connections will be made automatically.



When the Bluetooth® connection is complete, the mobile device information is stored, and the above Steps 3 and 4 are unnecessary from next time. Refer to page 33 to delete the stored mobile device information.




■ **To delete all mobile device information stored**

At first, set Bluetooth® functionality to [Enable]. (P.29)

**1. Display the menu screen.**

■ **When stopped**

Press .

■ **When operating**


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




**2. Select [Bluetooth].**

Press   → .





**3. Select [Initialization].**

Press   → .




**4. Start initialization.**

Press  →   → .

(Select [YES])


- Do not connect the mobile device via Bluetooth® functionality while initializing.



**5. Confirm that initialization has completed.**

Confirm, then press .

(Press 3 times to finish.)




**Note**

- Delete information of Bluetooth® connection with the remote controller stored on the mobile device as well.

## Basic settings screen

When Bluetooth® connection is successful, the following screen appears.




- Functions are not displayed in the “Panasonic H&C Control App” screen if the air conditioner does not support them.

## ■ Operation mode



Touch to select the operation mode.



- Auto mode is automatically switched to Cool or Heat to achieve the set temperature.
- Operation modes that cannot be set are not displayed.

## ■ Set temperature



Change set temperature (dial).

Change set temperature (+ or -).



### Fan speed




Change fan speed.

Auto fan toggle

- Cannot be selected in Fan mode.
- Depending on the model, selectable fan speed may differ.
- Depending on the model, either of the displays appears.



### Flap



Go to the screen for flap setting (P.37).

- Flap setting for each indoor unit

Go to the screen for locking individual flaps (P.38).

Change swing position.

Auto air swing toggle



- Press to stop swinging the flap at your preferred position.

- The swing position and the airflow direction shown on the screen are not synchronized with the actual flap movement.
- The flap display differs from the actual flap angle.

## ■ Flap setting for each indoor unit

### When setting flaps for each indoor unit

- Flaps of all air outlets of 1 indoor unit face the same direction.



Select the indoor unit.

- 1-1 → 1-2 to 1-8 (MAX) → ALL
- ALL: All units connected to the remote controller.

Change swing position.


Auto air swing toggle

- Press to stop swinging the flap at your preferred position.

### ■ Flap setting for each air outlet (Lock individual flap)

When setting the flap for each air outlet individually according to the room condition

- Even if the flap setting of all indoor units or each indoor unit (P.37) is changed, the flap directions set here are not changed.




- Select the indoor unit.
  - 1-1 → 1-2 to 1-8 (MAX) → ALL
  - ALL: All units connected to the remote controller.

- Change swing position
- Auto air swing toggle

All the air outlets


Select the air outlet



- The square mark (indented □) on the panel of the indoor unit indicates air outlet No. 1. There are some models that do not have a square mark (indented □).
- The air outlet No. changes according to the installation direction. Check by actual operation.

- For types other than the 4-way cassette type, this screen does not appear and this function cannot be used.

## ■ Power consumption monitor



Select the period to display

- You can view the power consumption (approx.).

## ■ Weekly timer

**You can set a weekly operation schedule.**

- The operation ON/OFF schedule or temperature setting schedule can be set by setting the day and time (e.g. 8:00 AM from every Monday to Friday).
- Up to 8 settings are available for each day.

The screenshot shows the 'Weekly timer' screen for Monday. At the top, there are icons for 'On/Off timer toggle' (checked for Enable, unchecked for Disable) and 'Add new timer'. Below is a table of saved settings:

No.	Time	Settings
1	23:00	16.0°C
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-

Annotations include: 'Show the list of saved template settings' pointing to the table; 'On/Off timer toggle' pointing to the checked box; 'Add new timer' pointing to the plus icon; 'Select the day of the week' pointing to the 'Monday' header; 'Change/delete timer' pointing to the star icon; 'Edit timer' pointing to the minus icon; 'Complete the settings' pointing to the 'Apply' button; and 'Copy timer' pointing to the 'Copy' button.

# Bluetooth® settings

## Add new timer

**Set time**

**Set conditions**

- Select temperature.
- Operation ON/OFF toggle
- Complete the settings.

## Change/delete timer

- Edit timer
- Change timer
- Delete timer

## Copy timer

- Select the day of the week (setting destination) to apply the settings  
• More than one can be selected.
- Complete the settings.



## ■ ON/OFF timer

This turns ON/OFF at the specified time. (e.g. Turning ON/OFF after 3 hours)



- Use OFF timer for example when: Reducing electric consumption while sleeping
- Use ON timer for example when: Operating the air conditioner according to the meeting start time.




Set the OFF timer.

Set the ON timer.



Cancel the OFF (ON) timer

- “Unset” is displayed when cancelled.



Edit timer


Complete the settings.


### ■ Energy saving

Refer to page 49 for information about the function.




Energy saving operation on/off toggle

 : Energy saving operation Off

 : Energy saving operation On

## Information

You can view information about the connected units.




Call a registered telephone number.

This provides the meanings of setting information icons. Details are displayed when you press the icon.

Air conditioner error messages

Displays the time remaining in hours until the next filter cleaning is required.

- Press “

Display remote controller information.

Display indoor unit information.

Display outdoor unit information.



# Bluetooth® settings

## ■ Menu list

The menus displayed when a remote controller is connected differ to the menus displayed when a remote controller is not connected.

When a remote controller is connected

When a remote controller is not connected



Depending on the model, there are some menus that are not available. The menu is not displayed in this case.

\* If the remote controller time is not set (Figure 1) or is wrong (Figure 2), set it in “Controller settings”. (There are functions such as the weekly timer that need the remote controller time to work.)

Figure 1




Figure 2



## ■ Application settings (Menu → Application settings)

Change the application's settings.

(Refer to page 46 to change the remote controller's settings.)



Change the display language of the application

Change the type of clock display of the application (12h/24h)

Change the type of Celsius/Fahrenheit display of the application

# Bluetooth® settings

## ■ Controller settings (Menu → Controller settings)

Change the remote controller's settings.

The screenshot shows the 'Controller settings' app interface. The settings are as follows:

- Controller name: CZ-RTC6BLW
- Controller language: English
- Controller clock: 2020/4/1 0:00
- Clock type: 24h
- Controller temperature sensor: Celsius
- Controller sound: On
- Touch sound: Off
- Contrast: Low
- Backlight: Dark
- Controller display mode: Standard
- Indoor units: Three units listed with model S-140PU2E5B and unit numbers -1-1, -2-1, and -3-1.


Callouts and their corresponding actions:

- Change the name of the remote controller
- Change the display language of the remote controller
- Set the present date and time of the remote controller
- Change the type of clock display of the remote controller
- The clock is synchronised with a mobile device.
- Change the Celsius/Fahrenheit display of the remote controller
- Remote controller operation sound on/off toggle
- Change the screen contrast of the remote controller
- Change the backlight brightness of the remote controller
- Change the display mode for the top screen of the remote controller
- Display indoor unit information

An inset window titled 'Set controller clock' shows a calendar for the year 2020. The date 2020/4/1 00:00 is selected. The window has 'Sync.' and 'OK' buttons.

■ ECONAVI settings  
(Menu → H&C settings → ECONAVI settings)

<b>Direct/Indirect airflow</b>	<ul style="list-style-type: none"> <li>• Direct airflow: When the ECONAVI sensor detects a person, the unit swings wind up and down around where the person is present.</li> <li>• Indirect airflow: The unit avoids directly hitting wind at a person's body.</li> </ul>
<b>Circulation (When using Panel for cassette (ECONAVI type) only)</b>	<ul style="list-style-type: none"> <li>• Cooling: If the ECONAVI sensor detects high temperature of the floor while group-controlling, the "Circulation" (air circulation) is performed to alleviate the unevenness of temperature between near the ceiling and near the floor.</li> <li>• Heating: If the ECONAVI sensor detects low temperature of the floor, the "Circulation" (air circulation) is performed to alleviate the unevenness of temperature between near the ceiling and near the floor.</li> </ul>



- ECONAVI function on/off toggle
- Set the Absence operation mode\*1.
- Set the time that elapses before the Absence operation mode starts.
- Set the direct/indirect airflow\*2.
- Circulation function on/off toggle



## Bluetooth® settings

### \*1: Types of the Absence operation mode

Select the Absence operation mode from among the following 4 options on the remote controller.

- **Not set**

If human activity is detected, the operation status is restored according to the level of human activity.

- **Standby**

Pauses the COOL/DRY or HEAT operation, and performs only the FAN (slight breeze) operation.

If human activity is detected, the operation status is restored according to the level of human activity.

- **Stop (no restart)**

Stops the operation. After stopped, the operation is not resumed even if human activity is detected.

- **Stop (restart)**

Stops the operation. After stopped, the operation is resumed if human activity is detected, and the operation status is restored according to the level of human activity.

### \*2: Types of the Direct/Indirect airflow

- **Not set**

Operation is performed with the set airflow direction without using the "Direct airflow/Indirect airflow".

- **Direct airflow**

The unit swings wind up and down around where the person is present.

- **Indirect airflow**

The unit avoids hitting wind at a person's body.



## ■ Energy saving (Menu → H&C settings → Energy saving)

### ● Temp. auto return

Restoring the changed temperature to the originally set temperature automatically after a specified time elapses. (e.g. Only when a guest comes)

### ● Temp. range


Restricting the temperature range that can be set. (Temperatures outside the range cannot be set.)

### ● Auto shutoff

When the operation is stopped at a specified time (e.g. closing time) and resumed afterwards, this function detects the operation status at regular time intervals and stops operation automatically. (e.g. 60 min)

### ● Repeat off timer

This stops operation after a certain period of time each time operation is performed. (e.g. When forgetting turning off)



Select the operation mode you want to set, then set the temperature and the time taken to reach the temperature.

On/off toggle (Enabled when blue.)

To operate only when energy saving is possible, select "Saving".

Select the operating mode you want to set, then set the temperature range.

On/off toggle (Enabled when blue.)

Auto shutoff on/off toggle

Time to stop operation (Time when Auto shutoff is activated)

Time when Auto shutoff stops


Time interval to detect operation status after [Stop time]

Repeat off timer on/off toggle.


Set the timer to stop.

## Bluetooth® settings


### ■ nanoeX settings (Menu → H&C settings → nanoeX settings)



### ■ Outing function (Menu → H&C settings → Outing function)




■ **Ventilation**  
(Menu → H&C settings → Ventilation)



Ventilation operation on/off toggle

■ **Internal drying**  
(Menu → H&C settings → Internal drying)




Internal drying function on/off toggle

## Bluetooth® settings

### ■ Administrator settings (Menu → Administrator settings)


Password entry is required to use the administrator settings.



Input the remote controller's password.

- The administrator settings are enabled for 10 minutes. You are logged out after 10 minutes. (There is a warning displayed 1 minute before.) The password needs to be entered again if you are logged out.
- The password also needs to be entered again if the “Panasonic H&C Control App” ends or if the Bluetooth® connection is interrupted.

■ Initial settings  
(Menu → Administrator settings → Initial settings)



Set whether to use the temperature sensor of the remote controller or the indoor units.

Change the Celsius/Fahrenheit display on the unit displayed on the remote controller

Change the ventilation output setting.

- **Set**  
When the air conditioner is turned ON/OFF, the connected ventilation fan is turned ON/OFF, too.
- To interlock the air conditioner and the fan, another installation work is required.

External device interlock on/off toggle

Select External device interlock mode

- **Human activity YES/NO**  
Synchronizes the presence/absence output of the motion sensor.
- **Indoor unit ON/OFF**  
Synchronizes the operation/stop output of the air conditioner.
- **Thermostat ON/OFF**  
Synchronizes the thermostat ON/OFF output of the air conditioner.

Duration of absence detection

- The operation-off timing can be changed. The setting can be made between 0 and 60 minutes by the minute.

Complete the settings.

## Bluetooth® settings

### ■ Schedule peak cut (Menu → Administrator settings → Schedule peak cut)

This reduces the operation capacity for the specified time period.

Enable/disable toggle

- : Enable
- : Disable

Add new setting

No.	Start time	End time	Capacity
1	0:00	1:00	60%
2	2:00	3:00	75%
3	-	-	-%
4	-	-	-%

Set the start time and end time and select the operation capacity.

Apply

Complete the settings.

### ■ Quiet operation (Menu → Administrator settings → Quiet operation)

Outdoor unit quiet operation on/off toggle

Set the time to perform quiet operation.


Confirm

Complete the settings.

## ■ Rotation settings (Menu → Administrator settings → Rotation settings)

### ● Rotation operation

Equalizes the operation time by stopping the operation in order. This prevents the operation time from being uneven depending on the refrigerant system.



- The rotation operation can be set only when controlling 2 refrigerant systems of Single split system (combination of 1 outdoor unit and 1 indoor unit) by one remote controller.

### ● Backup operation


The backup operation is a support operation performed by a refrigerant system in standby mode when the room temperature does not reach the set temperature due to poor performance or occurrence of an alarm.

Example: When an error occurs while System 1 is in operation and System 2 is in standby, System 2 will start up.

- In normal condition




- When an error occurs in System 1



# Bluetooth® settings

## ● ROTATION

(Menu → Administrator settings → Rotation settings → Rotation)




Change the rotation cycle  
• 1 to 7 days (by the day) / 14 days / 21 days / 28 days / Not set  
(Rotation operation OFF)

Set the switch-over time.

## ● BACKUP

(Menu → Administrator settings → Rotation settings → Backup)



Failure substitution on/off toggle  
• When this is set to ON, a system in standby mode will perform the support operation in case of alarm occurrence.


Temperature assist on/off toggle  
• **In Cool mode**  
Performs the support operation when the room temperature exceeds “set temperature + set value”.  
• **In Heat mode**  
Performs the support operation when the room temperature is below “set temperature + set value”.

Change the main system setting  
• **When “Cycle” is set**  
System that performs the preceding operation  
• **When “Cycle” is OFF**  
System that always performs the operation  
(The other system is a backup system.)

Complete the settings.




## ■ Operation lock (Menu → Administrator settings → Operation lock)



## ■ Password change (Menu → Administrator settings → Password change)


Change the remote controller's password.



### Note

- It is recommended that the password be changed periodically.


### ■ Group list (Menu → Group list)



### ■ Template settings (Menu → Template settings)


The settings for the weekly timer and the controller can be saved as templates even when there is no connection with the remote controller. When the connection is established with the remote controller, you can load the setting templates you have saved and apply them.

#### <How to set>



<How to load>

For the weekly timer



Show the list of saved template settings.



Select the settings to be loaded.

- The template settings are applied to the weekly timer.
- The original data is overwritten.


- The operations for controller settings templates are the same.

# Wireless LAN settings

Before use, confirm the version of the OS on the mobile device (P.95), and install the “Panasonic Comfort Cloud” app onto the mobile device. In addition, be sure to read the “General precautions for Wireless LAN functionality” (P.5).

## “Panasonic Comfort Cloud” app

You can use the “Panasonic Comfort Cloud” app on your mobile device to control the air conditioner when you are out and about.



### ■ Functions that can be set with the “Panasonic Comfort Cloud” app

- Operation start/stop, Operation mode, Set temperature, Fan speed, Flap
- Weekly timer\*1

The operation ON/OFF schedule or temperature setting schedule can be set by setting the day and time.

- Statistics\*2



Displays the approximate power consumption\*3, room temperature or outdoor temperature.

\*1 This is not synchronised with the Weekly timer set with the “Panasonic H&C Control App”.

\*2 The data for Statistics is collected on and managed by a Panasonic server. The power consumption data in particular may possibly show a difference to the data shown on the “Panasonic H&C Control App”.

\*3 Supported only by models that support the power consumption monitor

### ■ Installing the “Panasonic Comfort Cloud” app

For iOS user	For Android™ user
<ul style="list-style-type: none"> <li>• Open </li> <li>• Search for “Panasonic Comfort Cloud” app.</li> <li>• Download and install.</li> </ul>	<ul style="list-style-type: none"> <li>• Open </li> <li>• Search for “Panasonic Comfort Cloud” app.</li> <li>• Download and install.</li> </ul>

- You need to login with your Panasonic ID to use the “Panasonic Comfort Cloud” app. (P.63)
- There is no charge for using the “Panasonic Comfort Cloud” app. However, other charges may be incurred for connection and operation.
- The “Panasonic Comfort Cloud” app screen may change without notice due to updates.
- The screen operations are the same on iOS and Android™.
- The remote controller is available for use with all indoor units of commercial air conditioners released in April 2020 and after (PACi NX series and subsequent series) with names which start with “S-” except S-80/125MW1E5.


## Wireless LAN functionality

### 1 Display the menu screen.

#### ■ When stopped

Press .

#### ■ When operating


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




### 2 Select [WLAN].

Press   → .



### 3 Select [Enable/disable].

Press   → .





### 4 Select [Enable].



Press   →  → .

(Press twice to finish.)

- This can also be set using the procedure shown on page 30.
- [Enable] cannot be set for the Bluetooth® functionality and Wireless LAN functionality simultaneously.



#### To disable Wireless LAN functionality

1. Start with Step 1 and select [Disable] in Step 4.
2. Press .
3. Press  twice to finish.

#### Note

- Depending on the type of indoor unit, the display shown on the right may appear.



## Network status


At first, set Wireless LAN functionality to [Enable]. (P.61)

### 1 Display the menu screen.

■ **When stopped**

Press .

■ **When operating**


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




### 2 Select [WLAN].

Press   → .




### 3 Select [Network status].


Press   → .



### 4 Check the status of the connection to the wireless LAN network.





Confirm, then press .  
(Press 3 times to finish.)

- **Not connected to router**
- **Connecting to router**
- **Operating in Auto mode**
- **Operating in Manual mode**
- **Connected to router:**

“” is displayed on the top screen.

An icon is displayed to indicate the strength of the wireless LAN signal (table shown on the right).



Icon	Signal strength
	Strong
	Moderate
	Weak
	No signal

## Connecting network

At first, set Wireless LAN functionality to [Enable]. (P.61)  
Establish network connection to the internet via Wireless mode.

### ■ Before setting

- Confirm the wireless router is connected to the network and the router has access to the internet.
- Confirm the Wireless LAN of the mobile device is activated.
- Mobile device and air conditioner should be connected to the same wireless LAN.
- Ensure Wireless LAN is broadcasting SSID.

### ■ Setting flow

You will need to operate both the remote controller and the “Panasonic Comfort Cloud” app to perform these settings.

- ① Start the “Panasonic Comfort Cloud” app (Step 1)
- ② Connect wirelessly with a router (Step 2 - Step 5)
- ③ Register the information for the air conditioner on the server (Step 6 - Step 7)


#### < ① Start the “Panasonic Comfort Cloud” app >

### 1 Start the “Panasonic Comfort Cloud” app and login.

- If you do not have a Panasonic ID, create one and then login. (Refer to “To create new Panasonic ID” (P.72) for details.)

#### ■ Mobile device

Enter the information required for login and tap “Login”.



#### < ② Connect wirelessly with a router >

### 2 Add new air conditioner device.


- The air conditioner needs to be registered before using “Panasonic Comfort Cloud” app.

## Wireless LAN settings

1. At My Home screen, tap “+” to add new product.

- Mobile device


Tap “+”.



2. Select the “Commercial air conditioner” and choose the “Wired Remote controller”.

- Mobile device

Tap “Commercial air conditioner”.



Tap “Wired Remote controller”.





### 3 Make the settings for network connection.

1. After confirming that the **Wireless LAN functionality on the remote controller is set to [Enable] (P.61)**, tap “Next”.

#### ■ Remote controller

Follow the instructions on the app screen.

#### ■ Mobile device

Tap “Next”.



2. Select the option that matches the status displayed on the remote controller screen.


#### ■ Remote controller

Follow the instructions on the app screen.

#### ■ Mobile device

Tap to select the option.

- If you tapped “Not connected to router”, go to Step 4.
- If you tapped “Connected to router”, go to Step 6.



#### Note

- If the router supports the WPS mode, you can connect to the network with Auto mode. If you tapped “Click here to connect without entering a password.”, go to Step 5.

# 4 Connect to the network using Manual mode.


## 1. Make the remote controller operate in Manual mode.

### ■ Remote controller

Follow the instructions on the app screen.

### ■ Mobile device

Confirm that “Operating in Manual mode” is displayed, then tap “Next”.





## 2. Join to connect to the “Panasonic-CZ-C-wirelessAP” network.

### ■ Mobile device

(First time only)  
Tap “Allow While Using App”.  
Then, tap “Join”.


(Subsequent connections)  
Tap “Join”.



### 3. Enter the password of the selected wireless router and continue.

#### ■ Mobile device

Enter the password, then tap “OK”.




### 4. When the network connection to the router is successful, “Connected to router” is displayed on the remote controller screen.

- It may take some minutes for the connection to be established.

#### ■ Mobile device

Tap “Next”. Then, tap “Join”.



#### Note

- If “Connected to router” is displayed on the remote controller, connect the mobile device to wireless router. (return to this application after completing the wireless network settings to continue the setup)
- If the remote controller screen does not change to “Connected to router”, check the wireless LAN router connections.


■ This completes the settings for connecting to the router. Go to Step 6 to continue making the settings.

## 5 Connect to the network using Auto mode.

1. Press the WPS button on the router to establish connection.
2. Tap “Next” after the router is ready for connection.

### ■ Mobile device

Tap “Next”.




3. Make the remote controller operate in Auto mode.

### ■ Remote controller

Follow the instructions on the app screen.

### ■ Mobile device

Confirm that “Operating in Auto mode” is displayed then tap “Next”.




**4. When the network connection to the router is successful, “Connected to router” is displayed on the remote controller screen.**

- It may take some minutes for the connection to be established.

■ **Mobile device**

Tap “Next”.



**Note**

- If the remote controller screen does not change to “Connected to router”, check the wireless LAN router connections.

- **This completes the settings for connecting to the router. Go to Step 6 to continue making the settings.**


< ③ Register the information for the air conditioner on the server >

**6** Select the air conditioner and set the password.

**1. Select the air conditioner model to register the device.**

■ **Mobile device**

Tap the indoor unit model number to register.  
Then, tap “Register”.




**2. Make the remote controller operate in registration mode.**

■ **Remote controller**

Follow the instructions on the app screen.

■ **Mobile device**


Tap “Next”.



**3. Set a password for new air conditioner model to complete the registration. Password must be between 8-15 characters with letters and numbers.**

■ **Mobile device**

Tap and enter the password.  
Then, tap “Register”.



**Note**

- Keep the password for future use with additional user registrations.

## 7 Complete registration.


Once connection is established between the app and the new air conditioner, set a preferred name for this air conditioner to help identify it.

- By registering the new name of air conditioner, the function of “Panasonic Comfort Cloud” app is ready to be used.


### ■ Mobile device


Tap and enter the name.  
Then, tap “Register”.

### ■ Remote controller

Press .  
(Press twice to finish.)

- In addition to operation control, this application can monitor the estimated energy consumption and perform comparisons for different time frames by referring to the statistic's graph.



 is displayed on the top screen of the remote controller when network settings are completed.

The network information and air conditioner information are saved in the Wireless LAN module, so even if the power of the remote controller is lost due to a power failure, the connection with the network is automatically re-established using the saved information when power is restored.


### Note

- Confirm the “Panasonic Comfort Cloud” app’s screen connectivity status before or during operation, if the status is not reflected, use in-house remote controller to operate.

■ **To create new Panasonic ID**

If you do not have a Panasonic ID, create one and then login.  
Use “Panasonic Comfort Cloud” app as an option to control the air conditioner.

- For new user, select “Create new Panasonic ID” to register.
- For registered user, login using your Panasonic ID and password.




**Note**


- It is recommended that the password be changed periodically.



## Operating with the “Panasonic Comfort Cloud” app

Before use, confirm that the remote controller is connected to the router (“” is displayed on the top screen of the remote controller).

### Login



Panasonic ID

Password

Reset Panasonic ID / Password.

Register for new Panasonic ID.

Delete Panasonic ID.

Start a demonstration.

### ■ Home screen




1st group

Device

Add new device (P.63)

2nd group


Tap



This Operating Instructions can be found under Menu tab.

The “Panasonic Comfort Cloud” app is connected to the remote controller and ready for use.


## Main device screen



\* Features vary depending on air conditioner model.


### Information

This shows a list of users awaiting approval.




### Air conditioner status

Status of all air conditioners in the same group.



■ Statistics




\* Estimated energy consumption may not be supported by certain models.

Comparison




Information of date selected for comparison


- Dates are greyed out if data could not be obtained.



Date selection



Week selection



Month selection




Year selection


## ■ Weekly timer

<Add/edit timer>

1. Tap “Edit timer”.




2. Add new timer or edit timer.




# Wireless LAN settings

## 3. Set time and conditions.




## 4. Tap “Apply” to complete settings.



<Copy timer>


1. Tap "Edit timer".



Edit timer

ON/OFF timer toggle  
(Enable/disable)


2. Select the copy source day. Then, tap "Copy".




Select the day of the week.

# Wireless LAN settings

3. Select the day of the week (setting destination) to apply settings. Then, tap “OK”.




4. Tap “Apply” to complete settings.





## Main menu



## Wireless LAN settings

### ■ User list (Menu → Owner → User list)

The image shows two screenshots from a mobile application. The left screenshot is titled "User list" and displays a table of users for "My House" in the "Living room". The table has columns for "Note", "Edit", "Allow control", and "Delete". Users listed are UserA, UserB, UserC, UserD, and UserE. UserE has a "Waiting for approval" status. Annotations point to the "Edit" icon, the "Allow control" checkbox, and the "Delete" icon. The right screenshot is titled "User approval" and shows the approval options for UserE. It includes a text field for "Approval note" and three radio button options: "Do not approve", "Only allow monitoring air conditioner status", and "Allow both monitoring and controlling air conditioner". The third option is selected. A dashed orange box highlights these options, with an annotation "User's control rights" pointing to it. A "Confirm" button is at the bottom.

Edit the name of the user.

Enable control of user.

Edit / delete the user control.

User's control rights

### ■ Changing device password (Menu → Owner → Changing device password)


The image shows a screenshot of the "Changing device password" screen. It includes instructions: "Make sure the device is correct and enter old password and new password. Password must be 8-15 characters with letters and numbers." Below this, it shows the location "My House Living room" and the model "Model (main indoor unit) : S-...". There are three input fields: "Old password", "New password", and "Re-enter new password". A "Register" button is at the bottom. Annotations point to each of these three input fields.

Enter old password.

Enter new password.

Retype new password.


## ■ Replace device (Menu → Owner → Replace device)




Select "Replace device" from the menu.

Tap "Start".

Follow step-by-step instructions on the app.




## ■ Change router settings (Menu → Owner → Change router settings)



Select "Change router settings" from the menu.


Tap "Start".

Follow step-by-step instructions on the app.  
(Refer to page 65)



# Wireless LAN settings

## ■ Device list (Menu → Device list)



Edit device information and setting.




Edit device name.


Change device group.

Time zone selection


Features selection  
(Features vary depending on  
air conditioner model.)



Delete the device.



■ Group list  
(Menu → Group list)




# Restart

At first, set Wireless LAN functionality to [Enable]. (P.61)


When the wireless LAN communication is considered abnormal, reset the wireless LAN module hardware.

## 1 Display the menu screen.

### ■ When stopped

Press .

### ■ When operating


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .




## 2 Select [WLAN].

Press   → .



## 3 Select [Restart].

Press   → .



## 4 Restart.

Press  →   → .

(Select [YES])

→ .

(Press twice to finish.)



## Initialization

At first, set Wireless LAN functionality to [Enable]. (P.61)


Reset the wireless LAN settings to manufacturing default condition.

### 1 Display the menu screen.

#### ■ When stopped

Press .

#### ■ When operating


Press  repeatedly until the menu screen is displayed.

- To return to the top screen, press .



### 2 Select [WLAN].

Press   → .



### 3 Select [Initialization].


Press   → .



### 4 Start initialization.

Press  →   → .


(Select [YES])




### 5 Confirm that initialization has completed.

Confirm, then press .

(Press 3 times to finish.)



# Troubleshooting


If operation does not start by pressing ...

**Check the following before asking for repair.**


When the [START/  
STOP is prohibited.]  
message is displayed

- Being centrally controlled, operation is not possible.


Blackout?

- After recovery from blackout, press  again.  
→If operation does not start, turn off the circuit breaker and consult the dealer of purchase about the symptom and Model No.

Is the circuit breaker  
turned off?

- Turn it on and press  again.  
→If operation does not start, turn off the circuit breaker and consult the dealer of purchase about the symptom and Model No.

Is [Assigning]  
blinking?

- After blinking stops, press  again.  
→If operation does not start, turn off the circuit breaker and consult the dealer of purchase about the symptom and Model No.

Is  displayed?


Alarm indication (e.g.)






Defective indoor unit No.

- If any of the following alarm indications appears, stop operation once and restart approx. 1 minute later.  
(Alarm indication, off)  
[•E04 •E06 •P10 •P20 •H06]  
→If the indication does not reappear, use the unit.  
→If the indication reappears or an alarm indication other than the above (combination of numbers and characters such as E, F, H, L and P) appears, stop operation, turn off the circuit breaker and consult the dealer of purchase about alarm indication, Model No. and indoor unit No.





Cannot stop the operation.  
Or the unit starts to run automatically even if  (Off) button is pressed.



- Check if the outing function is activated or not. 
- Check control by central control device.

The remote controller screen displays “ ↔ “”.  
(alternately)

- Faulty sensor or incorrect installation.  
→ Turn OFF the ECONAVI function with the remote controller (P.15) and contact the retailer or point of purchase with the Model No. and problem.

The remote controller screen does not display the .

- The indoor unit has stopped. Turn on the indoor unit.
- The unit is in Fan mode . The ECONAVI function does not operate in Fan mode.
- The ECONAVI function is set to OFF. Turn the ECONAVI function ON with the remote controller. (P.15)
- The indoor unit may not support the ECONAVI function. If you turn the ECONAVI function ON with the remote controller but there is no change, the indoor unit does not support the ECONAVI function. Please contact the dealer.

The remote controller screen displays “ ↔ “”.  
(alternately)

- nanoe™ X is considered abnormal.  
→ Turn OFF the nanoe™ X function with the remote controller (P.17) and contact the retailer or point of purchase with the Model No. and problem.

**The remote controller screen displays**

“” ↔ “”.

(alternately)

- The clock has not been set.  
→Set the clock. (P.21)


**The Weekly timer does not operate according to the set time.**



- The weekly timer has been set on both the “Panasonic H&C Control App” and the “Panasonic Comfort Cloud” app.  
→Disable one of the timer settings. (P.39, P.77)
- If the timer is set on the “Panasonic Comfort Cloud” app, check that the Time zone setting is correct. (P.84)

**The “Panasonic H&C Control App” cannot be installed in mobile device.**



- Check if OS of the mobile device is compatible.  
The “Panasonic H&C Control App” is not guaranteed to work with all versions of iOS and Android™ OS.  
See page 95 for the versions of the OS for mobile devices that are supported by the “Panasonic H&C Control App” and the Bluetooth® versions.

**Remote controller and mobile device cannot be connected via Bluetooth® functionality.**

- Confirm that the remote controller is turned on.
- Check the following if “” is not displayed on the top screen.
  - Confirm that the Bluetooth® setting on the remote controller is set to [Enable]. (P.29)
  - If the mobile device to be connected by Bluetooth® functionality is far away from the remote controller, try getting it as close as possible to the remote controller.
  - Check the connection method of the remote controller and that of the mobile device (P.31).

**The remote controller screen displays “” ↔ “”.**  
(alternately)

- Bluetooth® module is considered abnormal.  
→Set Bluetooth® functionality to [Disable] with the remote controller (P.29) and contact the retailer or point of purchase with the Model No. and problem.

**The remote controller screen displays “” ↔ “”.**  
(alternately)

- Wireless LAN module is considered abnormal.  
→Refer to “Restart” (P.86) and restart the wireless LAN module. If it is displayed again, set Wireless LAN functionality to [Disable] with the remote controller (P.61) and contact the retailer or point of purchase with the Model No. and problem.


- If you need further assistance, see the contact information on the back cover of the operating instructions for indoor units or outdoor units.

## Wireless LAN functionality

**The “Panasonic Comfort Cloud” app cannot be installed in mobile device.**

- Check if OS of the mobile device is compatible.  
The “Panasonic Comfort Cloud” app is not guaranteed to work with all versions of iOS and Android™ OS.  
See page 95 for the versions of the OS for mobile devices that are supported by the “Panasonic Comfort Cloud” app.


**Remote controller and router cannot be connected.**

- Confirm that the remote controller is turned on.
- Check the following if “” is not displayed on the top screen of the remote controller.
  - Confirm that the Wireless LAN setting on the remote controller is set to [Enable]. (P.61)
  - Ensure the router’s wireless LAN signal reaches the remote controller, the SSID is not hidden, the MAC address setup is enabled for the remote controller, the router’s dual band signal is enabled for 2.4 GHz connection.
  - Check the network connections (P.62). Refer to the mobile device and router installation manual for details.

**Register additional air conditioner to “Panasonic Comfort Cloud” app.**

- Set the additional unit, following the first unit initial setup. It is recommended to name each of the registered air conditioner units to distinguish them easily.


**Register additional user to control the air conditioner.**

- Download “Panasonic Comfort Cloud” app and create new Panasonic ID. Follow initial setting. Once the air conditioner is registered, input the preset device password (set by first user). Approval from administrator (first user) is required to complete the registration. Select  Menu in the app. Choose “Owner” and select “User list” to approve additional user.

**The wireless signal has been cut off or interrupted.**


- It is possible that the network connection is not stable.  
→Refer to “Network status” (P.62) and check the strength of the signal.

**Suspicious unauthorised access to the air conditioner (remote controller).**

- Refer to “Initialization” (P.87) and initialize.  
To unregister the air conditioner unit from “Panasonic Comfort Cloud” app, select  Menu and choose “Device list” to delete the set unit.

**Functions set on the “Panasonic Comfort Cloud” app are not working. Statistics data is not displayed in the app.**

- Refer to “Connecting network” (P.63) to connect the remote controller to the router. If the remote controller is not connected to the router, statistics data may be not displayed in the app.



• If you need further assistance, see the contact information on the back cover of the operating instructions for indoor units or outdoor units.

# Specifications

<b>Model No.</b>	CZ-RTC6BLW / CZ-RTC6WBLW	
<b>Dimensions</b>	(H) 86 mm x (W) 86 mm x (D) 25 mm	
<b>Weight</b>	0.10 kg	
<b>Temperature/ Humidity range</b>	0 °C to 40 °C / 20% to 80% (No condensation) * Indoor use only.	
<b>Power Source</b>	DC16 V (supplied from indoor unit)	
<b>Clock</b>	<b>Precision</b>	± 30 seconds/month (at normal temperature 25 °C) * Adjust periodically.
	<b>Holding time</b>	24 hours (When fully charged) (at normal temperature 25 °C) * Approx. 8 hours are required for full charge.
<b>Number of connected indoor units</b>	Indoor unit: Up to 8 units (Within group-controlling)	
<b>OS version on the mobile device for “Panasonic H&amp;C Control App”</b>	Check on the relative app store for supported OS versions.	
<b>Bluetooth® version</b>	4.2 or later	
<b>Wireless LAN standard</b>	IEEE 802.11 b/g/n	
<b>Frequency range</b>	2.4 GHz band	
<b>Encryption</b>	WPA2-PSK (TKIP/AES)	
<b>OS version on the mobile device for “Panasonic Comfort Cloud” app</b>	Check on the relative app store for supported OS versions.	

- The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Panasonic Corporation is under license. Other trademarks and trade names are those of their respective owners.
- iOS is the name of the OS of Apple Inc. IOS is a trademark or registered trademark of Cisco in the US and other countries which has been licensed for use.
- Apple and the Apple logo are trademarks of Apple Inc. that are registered in the US and other countries. App Store is a service mark of Apple Inc.
- Android™, Google Play™ and Google Play™ logos are registered trademarks of Google LLC.

## Disposal of Old Equipment

### Only for European Union and countries with recycling systems



This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products must not be mixed with general household waste.

For proper treatment, recovery and recycling of old products, please take them to applicable collection points in accordance with your national legislation.

By disposing of them correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment. For more information about collection and recycling, please contact your local municipality.

Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.



#### Declaration of Conformity (DOC)

Hereby, "Panasonic Corporation" declares that this product is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address:

<http://www.ptc.panasonic.eu/>

Authorized Representative: Panasonic Testing Centre, Panasonic Marketing Europe GmbH, Winsbergring 15, 22525 Hamburg, Germany  
Norway: There are usage restrictions within a radius of 20 km from the centre of Ny-Alesund on Svalbard.



#### Declaration of Conformity (DOC)

Hereby, "Panasonic Corporation" declares that this product is in compliance with the essential requirements and other relevant provisions of the relevant statutory requirements.

The full text of the declaration of conformity is available at the following internet address:

<http://www.ptc.panasonic.eu/>

Contact in the UK:

Panasonic UK, a branch of Panasonic Marketing Europe GmbH,  
Maxis 2, Western Road, Bracknell, Berkshire, RG12 1RT



# Firmware Update Function for Wireless LAN functionality

This product has functionality for connecting to the Panasonic firmware update server over the Internet to automatically update the device firmware to the latest version. To update the firmware, the device will do check, once per day, whether its firmware is the latest version after power up. And if an update is required, the update is applied and the device restarts automatically. Operations are not possible while the device is being restarted (Requires a maximum of five minutes).

## Software License Information (Bluetooth<sup>®</sup> functionality)

This product incorporates the following software:

- (1) The software developed independently by or for Panasonic Corporation,
- (2) The software owned by third party and licensed to Panasonic Corporation,
- (3) The open source software under the Apache 2.0 license.
- (4) The open source software under the BSD license and/or equivalent license.

The software categorized as of (3), (4) is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY, without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

### mbedTLS

Copyright (C) 2006-2015, ARM Limited, All Rights Reserved

Apache License  
Version 2.0, January 2004  
<http://www.apache.org/licenses/>

### TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

#### 1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document. "Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work.

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner.

For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution." "Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

**2. Grant of Copyright License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

**3. Grant of Patent License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

**4. Redistribution.** You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:

- (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
- (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
- (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
- (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License.

You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License. You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

**5. Submission of Contributions.** Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions. Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.

**6. Trademarks.** This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.

**7. Disclaimer of Warranty.** Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.

**8. Limitation of Liability.** In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

**9. Accepting Warranty or Additional Liability.** While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and/or on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[ ]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.

# Software License Information (Wireless LAN functionality)

## Copyright①

- The App Store is a service mark of Apple Inc.
- iPhone is a trademark of Apple Inc. registered in the United States and other countries. The iPhone trademarks is used under license of iPhone Co., Ltd.
- Android and Google Play are trademarks or registered trademarks of Google LLC.
- Other names, company names, product names, etc described in this manual are trademarks or registered trademarks of each company. In the text, some <sup>TM</sup> and <sup>®</sup> marks are not listed.

### About Software

This product incorporates the following software:

- 1) The software developed independently by or for Panasonic Corporation,
- 2) The software owned by third party and licensed to Panasonic Corporation,
- 3) The software licensed under the GNU GENERAL PUBLIC LICENSE Version 2.0 (GPL V2.0),
- 4) Open sourced software other than the software licensed under the GPL V2.0.

The software categorized as (3) and (4) are distributed in the hope that it will be useful, but without any warranty, without even the implied warranty of [merchantability] or [fitness for a particular purpose]. Please refer to the detailed terms and conditions thereof shown in the "Software License" menu on this product.

At least three (3) years from delivery of this product, Panasonic will give to any third party who contacts us at the contact information provided below, for a charge no more than our cost of physically performing source code distribution, a complete machine-readable copy of the corresponding source code covered under GPL V2.0 or the other licenses with the obligation to do so, as well as the respective copyright notice thereof.

Contact information:

oss-cd-request@gg.jp.panasonic.com

The source code and the copyright notice are also available for free in our website below.

<https://panasonic.net/cns/oss/ap/>

Refer to the operating instructions on the Panasonic website for the most recent information.

### lwIP

lwIP is licenced under the BSD licence:

Copyright (c) 2001-2004 Swedish Institute of Computer Science.

All rights reserved.

Copyright (c) 2001-2003 Swedish Institute of Computer Science.

All rights reserved.

Copyright (c) 2002 CITEL Technologies Ltd. All rights reserved.

Copyright (c) 2007 Dominik Spies <kontakt@dspies.de> All rights reserved.

Copyright (c) 2002-2003, Adam Dunkels. All rights reserved.

Copyright (c) 2001-2003 Swedish Institute of Computer Science.

Copyright (c) 2003-2004 Leon Woestenberg <leon.woestenberg@axon.tv>

Copyright (c) 2003-2004 Axon Digital Design B.V., The Netherlands. All rights reserved.

Copyright (c) 2001-2004 Leon Woestenberg <leon.woestenberg@gmx.net>

Copyright (c) 2001-2004 Axon Digital Design B.V., The Netherlands. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

### mbdTLS

Copyright (C) 2006-2015, ARM Limited, All Rights Reserved

Copyright (C) 2006-2016, ARM Limited, All Rights Reserved

Apache License

Version 2.0, January 2004

<http://www.apache.org/licenses/>

TERMS AND CONDITIONS FOR USE, REPRODUCTION, AND DISTRIBUTION

#### 1. Definitions.

"License" shall mean the terms and conditions for use, reproduction, and distribution as defined by Sections 1 through 9 of this document.

"Licensor" shall mean the copyright owner or entity authorized by the copyright owner that is granting the License.

"Legal Entity" shall mean the union of the acting entity and all other entities that control, are controlled by, or are under common control with that entity. For the purposes of this definition, "control" means (i) the power, direct or indirect, to cause the direction or management of such entity, whether by contract or otherwise, or (ii) ownership of fifty percent (50%) or more of the outstanding shares, or (iii) beneficial ownership of such entity.

"You" (or "Your") shall mean an individual or Legal Entity exercising permissions granted by this License.

"Source" form shall mean the preferred form for making modifications, including but not limited to software source code, documentation source, and configuration files.

"Object" form shall mean any form resulting from mechanical transformation or translation of a Source form, including but not limited to compiled object code, generated documentation, and conversions to other media types.

"Work" shall mean the work of authorship, whether in Source or Object form, made available under the License, as indicated by a copyright notice that is included in or attached to the work (an example is provided in the Appendix below).

"Derivative Works" shall mean any work, whether in Source or Object form, that is based on (or derived from) the Work and for which the editorial revisions, annotations, elaborations, or other modifications represent, as a whole, an original work of authorship. For the purposes of this License, Derivative Works shall not include works that remain separable from, or merely link (or bind by name) to the interfaces of, the Work and Derivative Works thereof.

# Copyright<sup>2</sup>

"Contribution" shall mean any work of authorship, including the original version of the Work and any modifications or additions to that Work or Derivative Works thereof, that is intentionally submitted to Licensor for inclusion in the Work by the copyright owner or by an individual or Legal Entity authorized to submit on behalf of the copyright owner.

For the purposes of this definition, "submitted" means any form of electronic, verbal, or written communication sent to the Licensor or its representatives, including but not limited to communication on electronic mailing lists, source code control systems, and issue tracking systems that are managed by, or on behalf of, the Licensor for the purpose of discussing and improving the Work, but excluding communication that is conspicuously marked or otherwise designated in writing by the copyright owner as "Not a Contribution."

"Contributor" shall mean Licensor and any individual or Legal Entity on behalf of whom a Contribution has been received by Licensor and subsequently incorporated within the Work.

**2. Grant of Copyright License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable copyright license to reproduce, prepare Derivative Works of, publicly display, publicly perform, sublicense, and distribute the Work and such Derivative Works in Source or Object form.

**3. Grant of Patent License.** Subject to the terms and conditions of this License, each Contributor hereby grants to You a perpetual, worldwide, non-exclusive, no-charge, royalty-free, irrevocable (except as stated in this section) patent license to make, have made, use, offer to sell, sell, import, and otherwise transfer the Work, where such license applies only to those patent claims licensable by such Contributor that are necessarily infringed by their Contribution(s) alone or by combination of their Contribution(s) with the Work to which such Contribution(s) was submitted. If You institute patent litigation against any entity (including a cross-claim or counterclaim in a lawsuit) alleging that the Work or a Contribution incorporated within the Work constitutes direct or contributory patent infringement, then any patent licenses granted to You under this License for that Work shall terminate as of the date such litigation is filed.

**4. Redistribution.** You may reproduce and distribute copies of the Work or Derivative Works thereof in any medium, with or without modifications, and in Source or Object form, provided that You meet the following conditions:

- (a) You must give any other recipients of the Work or Derivative Works a copy of this License; and
- (b) You must cause any modified files to carry prominent notices stating that You changed the files; and
- (c) You must retain, in the Source form of any Derivative Works that You distribute, all copyright, patent, trademark, and attribution notices from the Source form of the Work, excluding those notices that do not pertain to any part of the Derivative Works; and
- (d) If the Work includes a "NOTICE" text file as part of its distribution, then any Derivative Works that You distribute must include a readable copy of the attribution notices contained within such NOTICE file, excluding those notices that do not pertain to any part of the Derivative Works, in at least one of the following places: within a NOTICE text file distributed as part of the Derivative Works; within the Source form or documentation, if provided along with the Derivative Works; or, within a display generated by the Derivative Works, if and wherever such third-party notices normally appear. The contents of the NOTICE file are for informational purposes only and do not modify the License. You may add Your own attribution notices within Derivative Works that You distribute, alongside or as an addendum to the NOTICE text from the Work, provided that such additional attribution notices cannot be construed as modifying the License.

You may add Your own copyright statement to Your modifications and may provide additional or different license terms and conditions for use, reproduction, or distribution of Your modifications, or for any such Derivative Works as a whole, provided Your use, reproduction, and distribution of the Work otherwise complies with the conditions stated in this License.

**5. Submission of Contributions.** Unless You explicitly state otherwise, any Contribution intentionally submitted for inclusion in the Work by You to the Licensor shall be under the terms and conditions of this License, without any additional terms or conditions.

Notwithstanding the above, nothing herein shall supersede or modify the terms of any separate license agreement you may have executed with Licensor regarding such Contributions.

**6. Trademarks.** This License does not grant permission to use the trade names, trademarks, service marks, or product names of the Licensor, except as required for reasonable and customary use in describing the origin of the Work and reproducing the content of the NOTICE file.

**7. Disclaimer of Warranty.** Unless required by applicable law or agreed to in writing, Licensor provides the Work (and each Contributor provides its Contributions) on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied, including, without limitation, any warranties or conditions of TITLE, NON-INFRINGEMENT, MERCHANTABILITY, or FITNESS FOR A PARTICULAR PURPOSE. You are solely responsible for determining the appropriateness of using or redistributing the Work and assume any risks associated with Your exercise of permissions under this License.

**8. Limitation of Liability.** In no event and under no legal theory, whether in tort (including negligence), contract, or otherwise, unless required by applicable law (such as deliberate and grossly negligent acts) or agreed to in writing, shall any Contributor be liable to You for damages, including any direct, indirect, special, incidental, or consequential damages of any character arising as a result of this License or out of the use or inability to use the Work (including but not limited to damages for loss of goodwill, work stoppage, computer failure or malfunction, or any and all other commercial damages or losses), even if such Contributor has been advised of the possibility of such damages.

**9. Accepting Warranty or Additional Liability.** While redistributing the Work or Derivative Works thereof, You may choose to offer, and charge a fee for, acceptance of support, warranty, indemnity, or other liability obligations and/or rights consistent with this License. However, in accepting such obligations, You may act only on Your own behalf and on Your sole responsibility, not on behalf of any other Contributor, and only if You agree to indemnify, defend, and hold each Contributor harmless for any liability incurred by, or claims asserted against, such Contributor by reason of your accepting any such warranty or additional liability.

END OF TERMS AND CONDITIONS

APPENDIX: How to apply the Apache License to your work.

To apply the Apache License to your work, attach the following boilerplate notice, with the fields enclosed by brackets "[]" replaced with your own identifying information. (Don't include the brackets!) The text should be enclosed in the appropriate comment syntax for the file format. We also recommend that a file or class name and description of purpose be included on the same "printed page" as the copyright notice for easier identification within third-party archives.

Copyright [yyyy] [name of copyright owner]

Licensed under the Apache License, Version 2.0 (the "License"); you may not use this file except in compliance with the License. You may obtain a copy of the License at

<http://www.apache.org/licenses/LICENSE-2.0>

Unless required by applicable law or agreed to in writing, software distributed under the License is distributed on an "AS IS" BASIS, WITHOUT WARRANTIES OR CONDITIONS OF ANY KIND, either express or implied.

See the License for the specific language governing permissions and limitations under the License.

=====  
Copyright (c) 2003-2016, Jouni Malinen  
<j@w1.fi> and contributors All Rights Reserved.  
This program is licensed under the BSD license (the one with  
advertisement clause removed).  
If you are submitting changes to the project, please see  
CONTRIBUTIONS file for more instructions.

#### License

-----  
This software may be distributed, used, and modified under the  
terms of BSD license:  
Redistribution and use in source and binary forms, with or without  
modification, are permitted provided that the following conditions  
are met:

1. Redistributions of source code must retain the above copyright  
notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above  
copyright notice, this list of conditions and the following disclaimer  
in the documentation and/or other materials provided with the  
distribution.
3. Neither the name(s) of the above-listed copyright holder(s) nor  
the names of its contributors may be used to endorse or promote  
products derived from this software without specific prior written  
permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT  
HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS  
OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED  
TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY  
AND FITNESS FOR A PARTICULAR PURPOSE ARE  
DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT  
OWNER OR CONTRIBUTORS BE LIABLE FOR ANY  
DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY,  
OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT  
LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR  
SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS  
INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY  
OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR  
TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING  
IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF  
ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

#### Free RTOS

The FreeRTOS source code is licensed by a "modified" GNU  
General Public License (GPL). The modification is provided in the  
form of an exception.

NOTE: The modification to the GPL is included to allow you to  
distribute a combined work that includes FreeRTOS without being  
obliged to provide the source code for proprietary components  
outside of the FreeRTOS kernel.

#### The FreeRTOS GPL Exception Text:

Any FreeRTOS source code, whether modified or in its original  
release form, or whether in whole or in part, can only be distributed  
by you under the terms of the GNU General Public License plus  
this exception. An independent module is a module which is not  
derived from or based on FreeRTOS.

#### Clause 1:

Linking FreeRTOS statically or dynamically with other modules is  
making a combined work based on FreeRTOS. Thus, the terms  
and conditions of the GNU General Public License cover the whole  
combination.

As a special exception, the copyright holder of FreeRTOS gives  
you permission to link FreeRTOS with independent modules that  
communicate with FreeRTOS solely through the FreeRTOS API  
interface, regardless of the license terms of these independent  
modules, and to copy and distribute the resulting combined work  
under terms of your choice, provided that

+ Every copy of the combined work is accompanied by a  
written statement that details to the recipient the version  
of FreeRTOS used and an offer by yourself to provide the  
FreeRTOS source code (including any modifications you may  
have made) should the recipient request it.

+ The combined work is not itself an RTOS, scheduler, kernel  
or related product.

+ The independent modules add significant and primary  
functionality to FreeRTOS and do not merely extend the  
existing functionality already present in FreeRTOS.

#### Clause 2:

FreeRTOS may not be used for any competitive or comparative  
purpose, including the publication of any form of run time or  
compile time metric, without the express permission of Real Time  
Engineers Ltd. (this is the norm within the industry and is intended  
to ensure information accuracy).

#### The standard GPL exception text:

#### GNU GENERAL PUBLIC LICENSE

Version 2, June 1991

Copyright (C) 1989, 1991 Free Software Foundation, Inc. 59  
Temple Place, Suite 330, Boston, MA 02111-1307 USA  
Everyone is permitted to copy and distribute verbatim copies of this  
license document, but changing it is not allowed.

#### Preamble

The licenses for most software are designed to take away your  
freedom to share and change it. By contrast, the GNU General  
Public License is intended to guarantee your freedom to share  
and change free software—to make sure the software is free for all  
its users. This General Public License applies to most of the Free  
Software Foundation's software and to any other program whose  
authors commit to using it. (Some other Free Software Foundation  
software is covered by the GNU Library General Public License  
instead.) You can apply it to your programs, too.

When we speak of free software, we are referring to freedom,  
not price. Our General Public Licenses are designed to make sure  
that you have the freedom to distribute copies of free software (and  
charge for this service if you wish), that you receive source code  
or can get it if you want it, that you can change the software or use  
pieces of it in new free programs; and that you know you can do  
these things.

To protect your rights, we need to make restrictions that forbid  
anyone to deny you these rights or to ask you to surrender the  
rights. These restrictions translate to certain responsibilities for you  
if you distribute copies of the software, or if you modify it.

For example, if you distribute copies of such a program, whether  
gratis or for a fee, you must give the recipients all the rights that  
you have. You must make sure that they, too, receive or can get the  
source code. And you must show them these terms so they know  
their rights.

We protect your rights with two steps: (1) copyright the software,  
and (2) offer you this license which gives you legal permission to  
copy, distribute and/or modify the software.

Also, for each author's protection and ours, we want to make  
certain that everyone understands that there is no warranty for  
this free software. If the software is modified by someone else and  
passed on, we want its recipients to know that what they have is  
not the original, so that any problems introduced by others will not  
reflect on the original authors' reputations.

Finally, any free program is threatened constantly by software  
patents. We wish to avoid the danger that redistributors of a free  
program will individually obtain patent licenses, in effect making the  
program proprietary. To prevent this, we have made it clear that any  
patent must be licensed for everyone's free use or not licensed at all.

# Copyright<sup>③</sup>

The precise terms and conditions for copying, distribution and modification follow.

## GNU GENERAL PUBLIC LICENSE TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole to no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns. Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.

#### NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

END OF TERMS AND CONDITIONS

#### How to Apply These Terms to Your New Programs

If you develop a new program, and you want it to be of the greatest possible use to the public, the best way to achieve this is to make it free software which everyone can redistribute and change under these terms.

To do so, attach the following notices to the program. It is safest to attach them to the start of each source file to most effectively convey the exclusion of warranty; and each file should have at least the "copyright" line and a pointer to where the full notice is found.

<one line to give the program's name and a brief idea of what it does.>

Copyright (C) <year> <name of author>

This program is free software; you can redistribute it and/or modify it under the terms of the GNU General Public License\*\* as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

You should have received a copy of the GNU General Public License along with this program; if not, write to the Free Software Foundation, Inc., 59 Temple Place, Suite 330, Boston, MA 02111- 1307 USA

Also add information on how to contact you by electronic and paper mail.

If the program is interactive, make it output a short notice like this when it starts in an interactive mode:

Gnomovision version 69, Copyright (C) year name of author  
Gnomovision comes with ABSOLUTELY NO WARRANTY; for details type 'show w'.

This is free software, and you are welcome to redistribute it under certain conditions; type 'show c' for details.

The hypothetical commands 'show w' and 'show c' should show the appropriate parts of the General Public License. Of course, the commands you use may be called something other than 'show w' and 'show c'; they could even be mouse-clicks or menu items-- whatever suits your program.

You should also get your employer (if you work as a programmer) or your school, if any, to sign a "copyright disclaimer" for the program, if necessary. Here is a sample; alter the names:

Yoyodyne, Inc., hereby disclaims all copyright interest in the program 'Gnomovision' (which makes passes at compilers) written by James Hacker.

<signature of Ty Coon>, 1 April 1989

Ty Coon, President of Vice

This General Public License does not permit incorporating your program into proprietary programs. If your program is a subroutine library, you may consider it more useful to permit linking proprietary applications with the library. If this is what you want to do, use the GNU Library General Public License instead of this License.

#### newlib

The newlib subdirectory is a collection of software from several sources.

Each file may have its own copyright/license that is embedded in the source file. Unless otherwise noted in the body of the source file(s), the following copyright notices will apply to the contents of the newlib subdirectory:

(1) Red Hat Incorporated

Copyright (c) 1994-2009 Red Hat, Inc. All rights reserved.

This copyrighted material is made available to anyone wishing to use, modify, copy, or redistribute it subject to the terms and conditions of the BSD License. This program is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY expressed or implied, including the implied warranties of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. A copy of this license is available at <http://www.opensource.org/licenses>. Any Red Hat trademarks that are incorporated in the source code or documentation are not subject to the BSD License and may only be used or replicated with the express permission of Red Hat, Inc.

## Copyright④

(2) University of California, Berkeley  
Copyright (c) 1981-2000 The Regents of the University of California.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- \* Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- \* Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- \* Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(3) David M. Gay (AT&T 1991, Lucent 1998)

The author of this software is David M. Gay.

Copyright (c) 1991 by AT&T.

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, NEITHER THE AUTHOR NOR AT&T MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

-----  
The author of this software is David M. Gay.

Copyright (C) 1998-2001 by Lucent Technologies  
All Rights Reserved

Permission to use, copy, modify, and distribute this software and its documentation for any purpose and without fee is hereby granted, provided that the above copyright notice and this permission notice and warranty disclaimer appear in supporting documentation, and that the name of Lucent or any of its entities not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

LUCENT DISCLAIMS ALL WARRANTIES WITH REGARD TO THIS SOFTWARE, INCLUDING ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS. IN NO EVENT SHALL LUCENT OR ANY OF ITS ENTITIES BE LIABLE FOR ANY SPECIAL, INDIRECT OR CONSEQUENTIAL DAMAGES OR ANY DAMAGES WHATSOEVER RESULTING FROM LOSS OF USE, DATA OR PROFITS, WHETHER IN AN ACTION OF CONTRACT, NEGLIGENCE OR OTHER TORTIOUS ACTION, ARISING OUT OF OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THIS SOFTWARE.

(4) Advanced Micro Devices

Copyright 1989, 1990 Advanced Micro Devices, Inc.

This software is the property of Advanced Micro Devices, Inc (AMD) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by AMD.

AMD MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL AMD BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the 29K Technical Support Center at 800-29-29-AMD (800-292-9263) in the USA, or 0800-89-1131 in the UK, or 0031-11-1129 in Japan, toll free. The direct dial number is 512-462-4118.

Advanced Micro Devices, Inc.

29K Support Products

Mail Stop 573

5900 E. Ben White Blvd.

Austin, TX 78741

800-292-9263

(7) Sun Microsystems

Copyright (C) 1993 by Sun Microsystems, Inc. All rights reserved.

Developed at SunPro, a Sun Microsystems, Inc. business.

Permission to use, copy, modify, and distribute this software is freely granted, provided that this notice is preserved.

(8) Hewlett Packard

(c) Copyright 1986 HEWLETT-PACKARD COMPANY

To anyone who acknowledges that this file is provided "AS IS" without any express or implied warranty:

permission to use, copy, modify, and distribute this file for any purpose is hereby granted without fee, provided that the above copyright notice and this notice appears in all copies, and that the name of Hewlett-Packard Company not be used in advertising or publicity pertaining to distribution of the software without specific, written prior permission.

Hewlett-Packard Company makes no representations about the suitability of this software for any purpose.

(9) Hans-Peter Nilsson

Copyright (C) 2001 Hans-Peter Nilsson

Permission to use, copy, modify, and distribute this software is freely granted, provided that the above copyright notice, this notice and the following disclaimer are preserved with no changes.

THIS SOFTWARE IS PROVIDED "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

(11) Christopher G. Demetrio

Copyright (c) 2001 Christopher G. Demetrio

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED.



IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(12) SuperH, Inc.

Copyright 2002 SuperH, Inc. All rights reserved

This software is the property of SuperH, Inc (SuperH) which specifically grants the user the right to modify, use and distribute this software provided this notice is not removed or altered. All other rights are reserved by SuperH.

SUPERH MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS SOFTWARE. IN NO EVENT SHALL SUPERH BE LIABLE FOR INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES IN CONNECTION WITH OR ARISING FROM THE FURNISHING, PERFORMANCE, OR USE OF THIS SOFTWARE.

So that all may benefit from your experience, please report any problems or suggestions about this software to the SuperH Support Center via e-mail at [softwaresupport@superh.com](mailto:softwaresupport@superh.com).

SuperH, Inc.

405 River Oaks Parkway

San Jose

CA 95134

USA

(13) Royal Institute of Technology

Copyright (c) 1999 Kungliga Tekniska Högskolan

(Royal Institute of Technology, Stockholm, Sweden).

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. Neither the name of KTH nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY KTH AND ITS CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL KTH OR ITS CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(14) Alexey Zelkin

Copyright (c) 2000, 2001 Alexey Zelkin <[phantom@FreeBSD.org](mailto:phantom@FreeBSD.org)>

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(15) Andrey A. Chernov

Copyright (C) 1997 by Andrey A. Chernov, Moscow, Russia.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(16) FreeBSD

Copyright (c) 1997-2002 FreeBSD Project.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## Copyright<sup>5</sup>

(17) S. L. Moshier  
Author: S. L. Moshier.  
Copyright (c) 1984,2000 S.L. Moshier

Permission to use, copy, modify, and distribute this software for any purpose without fee is hereby granted, provided that this entire notice is included in all copies of any software which is or includes a copy or modification of this software and in all copies of the supporting documentation for such software.

THIS SOFTWARE IS BEING PROVIDED "AS IS", WITHOUT ANY EXPRESS OR IMPLIED WARRANTY. IN PARTICULAR, THE AUTHOR MAKES NO REPRESENTATION OR WARRANTY OF ANY KIND CONCERNING THE MERCHANTABILITY OF THIS SOFTWARE OR ITS FITNESS FOR ANY PARTICULAR PURPOSE.

(18) Citrus Project  
Copyright (c)1999 Citrus Project,  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(19) Todd C. Miller  
Copyright (c) 1998 Todd C. Miller <Todd.Miller@courtesan.com>  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the author may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(20) DJ Delorie (i386)  
Copyright (C) 1991 DJ Delorie  
All rights reserved.

Redistribution, modification, and use in source and binary forms is permitted provided that the above copyright notice and following paragraph are duplicated in all such forms.

This file is distributed WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE.

(23) Intel (i960)  
Copyright (c) 1993 Intel Corporation

Intel hereby grants you permission to copy, modify, and distribute this software and its documentation. Intel grants this permission provided that the above copyright notice appears in all copies and that both the copyright notice and this permission notice appear in supporting documentation. In addition, Intel grants this permission provided that you prominently mark as "not part of the original" any modifications made to this software or documentation, and that the name of Intel Corporation not be used in advertising or publicity pertaining to distribution of the software or the documentation without specific, written prior permission.

Intel Corporation provides this AS IS, WITHOUT ANY WARRANTY, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Intel makes no guarantee or representations regarding the use of, or the results of the use of, the software and documentation in terms of correctness, accuracy, reliability, currentness, or otherwise; and you rely on the software, documentation and results solely at your own risk.

IN NO EVENT SHALL INTEL BE LIABLE FOR ANY LOSS OF USE, LOSS OF BUSINESS, LOSS OF PROFITS, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES OF ANY KIND. IN NO EVENT SHALL INTEL'S TOTAL LIABILITY EXCEED THE SUM PAID TO INTEL FOR THE PRODUCT LICENSED HEREUNDER.

(26) Mike Barcroft  
Copyright (c) 2001 Mike Barcroft <mike@FreeBSD.org>  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(27) Konstantin Chuguev (--enable-newlib-iconv)  
Copyright (c) 1999, 2000

Konstantin Chuguev. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

iconv (Charset Conversion Library) v2.0

(28) Artem Bityuckiy (--enable-newlib-iconv)

Copyright (c) 2003, Artem B. Bityuckiy, SoftMine Corporation.

Rights transferred to Franklin Electronic Publishers.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(30) - Alex Tatmanjants (targets using libc/posix)

Copyright (c) 1995 Alex Tatmanjants <alex@elvisti.kiev.ua>

at Electronni Visti IA, Kiev, Ukraine.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(31) - M. Warner Losh (targets using libc/posix)

Copyright (c) 1998, M. Warner Losh <imp@freebsd.org>

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(32) - Andrey A. Chernov (targets using libc/posix)

Copyright (C) 1996 by Andrey A. Chernov, Moscow, Russia.

All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## Copyright⑥

(33) - Daniel Eischen (targets using libc/posix)  
Copyright (c) 2001 Daniel Eischen <deischen@FreeBSD.org>.  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(35) - ARM Ltd (arm and thumb variant targets only)  
Copyright (c) 2009 ARM Ltd  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. The name of the company may not be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY ARM LTD "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL ARM LTD BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

(41) Ed Schouten - Free BSD  
Copyright (c) 2008 Ed Schouten <ed@FreeBSD.org>  
All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

## Setting Information

Indoor unit model name	
Indoor unit serial number	
Outdoor unit model name	
Outdoor unit serial number	
System commissioning date	
Remote controller installation date	

## Installer Contact Details

Name	
Telephone number	

## Maximum radio-frequency power transmitted in the frequency bands

Type of wireless	Frequency band	Max EIRP (dBm)
Bluetooth® functionality	2402 - 2480 MHz	6.7 dBm
Wireless LAN functionality	2412 - 2472 MHz	20 dBm

## Regulatory Information

Model No. **CZ-RTC6BLW**






Dilarang melakukan perubahan spesifikasi yang dapat menimbulkan gangguan fisik dan/atau elektromagnetik terhadap lingkungan sekitarnya

69935 / SDPPI / 2020  
3903



เครื่องโทรคมนาคมและอุปกรณ์นี้มีความสอดคล้องตามข้อกำหนดของ กทช./กสทช.  
This telecommunication equipment conforms to NTC/NBTC technical requirement



**NTC**  
**Type Accepted**  
**No. ESD-RCE-2023720**

Model No. **CZ-RTC6WBLW**

 **R-NZ**

Contact in the UK

Panasonic UK, a branch of Panasonic  
Marketing Europe GmbH, Maxis 2,  
Western Road, Bracknell, Berkshire, RG12 1RT

Authorized representative in EU

Panasonic Testing Centre  
Panasonic Marketing Europe GmbH  
Winsbergring 15, 22525 Hamburg, Germany

Panasonic Corporation  
<http://www.panasonic.com>

© Panasonic Corporation 2020 - 2023

WEB-ACXF55-27554-EN  
F0820-60223