


Quick Guide for 4K Photo

Using the 4K Photo function to capture the best shot of the subject ([4K Burst] / [4K Burst(S/S)] / [4K Pre-Burst])


You can select the desired moment from a burst of pictures taken at 30 frames/second and save that moment as a picture of 8 million pixels (approx.).

① Recording 4K photos

- 1 Press (▼).
- 2 Press ◀/▶ to select a 4K photo icon (, etc.), and press ▲.
- 3 Press ◀/▶ to select the recording method, and press [MENU/SET].



Cursor button



Shutter button



[4K Burst]




For capturing the best shot of a fast-moving subject
(e.g., sports, aeroplanes, trains)

Burst recording is performed while the shutter button is pressed and held. The shutter sound will be heard repeatedly.

- 1 Press the shutter button halfway.
- 2 Press and hold the shutter button fully for as long as you want to perform recording.

- Press the button fully slightly in advance. Recording starts approximately 0.5 seconds after it has been pressed fully.



- (A) Press and hold
- (B) Recording is performed



[4K Burst(S/S)]




For capturing unpredictable photo opportunities
(e.g., plants, animals, children)

Burst recording starts when the shutter button is pressed and stops when pressed again. Start and stop tones will be heard.

- 1 Press the shutter button fully.
- 2 Press the shutter button fully again.

- When you press the [Fn2] button while recording, you can add a marker. When selecting and saving pictures from a 4K burst file, you can skip to the positions where you added markers.



- (C) Start (First)
- (D) Stop (Second)
- (E) Recording is performed



[4K Pre-Burst]




For recording as needed whenever a photo opportunity arises
(e.g., the moment when a ball is thrown)

Burst recording is performed for approximately 1 second before and after the moment that the shutter button is pressed. The shutter sound will be heard only once.

- 1 Press the shutter button fully.

- In situations where you want to lock focus and exposure, such as when the subject is not at the centre, use [AF/AE Lock].



- (F) Approximately 1 second
- (G) Recording is performed



■ Cancelling 4K Photo: Select [] ([Single]) or [] in step 2.

- Burst pictures are saved as a single 4K burst file in the MP4 format.
- Use a UHS Speed Class 3 card to record 4K photos.
- When recording 4K photos, the angle of view is narrower.
- If you are using Auto Focus, Continuous AF will work while recording. Focus will be adjusted continuously.
- You can reduce the blur of the subject by setting a faster shutter speed.
Approximate shutter speed for outdoor recording in fine weather conditions: 1/1000 seconds or faster.
- Recording stops when the continuous recording time exceeds 15 minutes.
When using an SDHC memory card, you can continue the recording of a 4K photo without interruption even if the file size exceeds 4 GB, but the 4K photo will be recorded and played back in separate burst files.
With an SDXC memory card, you can save a 4K photo with a burst file size exceeding 4 GB as a single file.
- If the surrounding temperature is high or 4K photos are recorded continuously, [] may be displayed and recording may be stopped halfway through. Wait until the camera cools down.
- When [] ([4K Pre-Burst]) is set, the battery drains faster and the camera temperature rises. (To protect itself, the camera may switch to [] ([4K Burst]).) Select [] ([4K Pre-Burst]) only when recording.

② Selecting pictures from 4K burst file and saving

Markers have been set by the camera automatically on a scene in which a face or the movement of a subject is detected during recording, for example, at the scene when a vehicle passes by or a person turns around. (Auto Marking)

- 1 Press [▶].
- 2 Press ◀/▶ to select an image indicated with the [▲] icon.
- 3 Press ▲.
 - If the image was recorded with [] (4K Pre-Burst), proceed to step 5.
- 4 Drag the slide bar to make a rough selection of scenes.
 - You can skip to a marked position by touching the marker.
 - White marker:** Manually set marker / **Green marker:** Marker set by the camera automatically
- 5 Drag the frames to select the frame you want to save as a picture.
- 6 Touch [] to save the picture.
 - The picture will be saved in JPEG format.



Showing movement by combining a sequence of pictures ([Sequence Composition])

- 1 Select [Sequence Composition] from the [Playback] menu.
 - [MENU/SET] → [▶][Playback] → [Sequence Composition]
- 2 Press ◀/▶ to select the 4K burst files, and press [MENU/SET].
- 3 Select frames to combine (from 3 to 40 frames).
- 4 Press ▲/▼ to select [Save], and press [MENU/SET].




Controlling Focus After Recording (Post Focus/Focus Stacking)

The camera can perform Burst recording in the same picture quality as 4K photo recording while automatically shifting the focus to different areas. After the recording, you can select the desired area on the screen and save a picture in which the selected area is in focus.

① Recording using [Post Focus]

• We recommend that you use a tripod when recording images to be used for Focus Stacking.


- 1 Press [] (▼).
- 2 Press ◀/▶ to select a Post Focus icon ([]), and press [MENU/SET].
- 3 Decide on the composition, and press the shutter button halfway.
- 4 Press the shutter button fully to start recording.



- **Cancelling [Post Focus]:**
Select [] ([Single]) or [] in step 2.

② Selecting the desired focus area and saving a picture

- 1 Press [▶].
- 2 Press ◀/▶ to select an image indicated with the [▲] icon, and press ▲.
- 3 Touch the desired focus area.
 - If a picture that is in focus is not available for the selected area, a red frame will be displayed. You cannot save a picture in this case.
- 4 Touch [] to save the picture.
 - The picture will be saved in JPEG format.



③ Using Focus Stacking and saving a picture

You can also merge multiple pictures with different focus areas to widen the focus range. (Focus Stacking)

- 1 Touch [] in step 3 of "Selecting the desired focus area and saving a picture".
- 2 Touch the merging method.

[Auto Merging]

Automatically selects pictures that are suited to be merged, and merges them into a single picture.

- Priority will be given to pictures with closer focus.
- Perform the focus stacking and save the picture.

[Range Merging]

Merges pictures with specified focus areas into a single picture.

(When [Range Merging] is selected)

- 3 Touch the desired focus area.
 - Specify at least two areas.
 - In-focus areas between the selected two points are indicated.
 - Parts that cannot be selected are indicated in grey.
 - Touch again to cancel the selection.
- 4 Touch [] to merge the pictures and save the resulting picture.
 - The picture will be saved in JPEG format.

